


RTP-CC

Converter ccTalk for Hopper parallel



+12~24V	= OUT ;Power supply for hopper ,by BUS ccTalk
GND	= OUT ;GND for hopper
COIN_RETURN	= INPUT ;Coin return pay ,(active <1) input optocoupler
START_HOPPER	= OUT ;Start hopper,active low open collector.
EMPTY	= INPUT;Empty hopper ,higt >2,3V Empty,Low <1 Full
SW1	= NOT USED
Led status	= Led status and error Attivo/Busy
F1	= Fuse 2A , protect line output

• Wiring of the RTP-CC

Connect the hopper in parallel, via the START PAY and COIN_RETURN signals and if necessary EMPTY, if you do not use EMPTY connect the signal to GND, the power supply is available in the terminal block and is supplied by the ccTalk bus, it is possible to use an external power supply provided that GND of the power supply and GND of the terminal block are connected together.

With the device turned off, connect the RTP-CC to the machine like a standard ccTalk hopper, using the 10-pin IDC connector.